

Technical Reference - Q&A

1. **Q:** I have a motherboard with Realtek HD Audio Codec. When I use Windows XP SP3 or upgrade to Windows XP SP3, the onboard audio doesn't work. What could I try?

A: Please try the Realtek latest audio driver.


The driver is available from this link:

<http://www.realtek.com.tw/downloads/downloadsView.aspx?Langid=1&PNid=14&PFid=24&Level=4&Conn=3&DownTypeID=3&GetDown=false>

2. **Q:** When I connect a HDMI_SPDIF cable from the HDMI VGA card (GTX260 or GF9800) to the onboard HDMI_SPDIF header, it cannot get sound from the HDMI output. What should I do?

A: The pin definition of the onboard HDMI_SPDIF header is different from the header of some VGA cards.

Please plug in the HDMI_SPDIF cable reversely like following picture.





3. **Q:** I use a Samsung SATA optical device (SH-203) on ALiveNF6P-VSTA. How do I get the system to work under Windows XP properly?

A: Please update NVIDIA 10.3.0.21IDE driver.

You are able to download the driver from following link.

<http://www.asrock.com/mb/download.asp?Model=ALiveNF6P-VSTA>

	2008/11/19	Windows XP	8.57MB	IDE(non-RAID) driver ver:10.3.0.21	
---	------------	------------	--------	------------------------------------	---