X570/B550 Taichi Razer Edition RGB firmware update

Please flash the RGB controller firmware by following the steps below.

Step 1.

Download the firmware file from ASRock website and extract the compressed files.

https://www.asrock.com/MB/AMD/X570%20Taichi%20Razer%20Edition/Specification.asp#BIOS

https://www.asrock.com/MB/AMD/B550%20Taichi%20Razer%20Edition/Specification.asp#BIOS

Step 2.

Execute “UpdateFW.cmd” to update the RGB controller firmware.



Step 3.

After step 2 please wait for 10 seconds or so and the firmware flash will finish.



Step 4.

After the message “update firmware SUCCESS” is shown, please shut down the system and switch off the power supply for 1 minute.

Step 5.

Please switch on the power supply and start the system.

Step 6.

After the system has started Windows please go to the notification area. Make sure the Razer icon is shown.



Step 7.

Restart the system and then you can open Razer Synapse 3 to configure the RGB lighting of your Razer devices.